

動作確認済 FOMA 端末一覧(2012年 12月 1日現在)

F	F-01A	F-01B	F-01C	704i series	SO704i	904i series	N904i
	F-02A	F-02B	F-02C		F704i		SH904i
	F-03A	F-03B			SH704i		F904i
	F-04A	F-04B			D704i		D904i
		F-06B			P704i		P904i
		F-07B			N704i μ	905i series	D905i
	F-08A	F-08B			P704i μ		F905i
	F-09A				L704i		N905i
N	N-01A	N-01B	N-01C	705i series	P704i μ		P905i
	N-02A		N-02C		L704i		SH905i
	N-03A	N-03B			D705i		SO905i
	N-04A	N-04B			N705i		N905i μ
	N-05A	N-05B			SH705i		N905iBiz
	N-06A	N-06B			SO705i		SH905iTV
	N-07A	N-07B			L705i		SO905iCS
	N-08A				L705iX		P905iTV
	N-09A				N705i μ		F905iBiz
P	P-01A	P-01B	P-01C	706i series	P705i μ	906i series	P906i
	P-02A	P-02B	P-02C		D705i μ		SO906i
	P-03A	P-03B	P-03C		P705iCL		F906i
	P-04A				SH705i II		SH906i
	P-05A	P-05B			F706i		N906i μ
	P-06A	P-06B			N706i		N906i
	P-07A	P-07B			SO706i		N906iL
	P-08A				SH706i		SH906iTV
	P-09A				P706i μ		
	P-10A				L706ie		
SH	SH-01A	SH-02B	SH-01C		N706ie		
	SH-02A	SH-03B	SH-02C		P706ie		
	SH-03A				SH706ie		
	SH-04A		SH-04C		SH706iw		
	SH-05A	SH-05B			N706i II		
	SH-06A	SH-06B					
	SH-07A	SH-07B					
	SH-08A	SH-08B					
L	L-01A	L-01B	L-01C				
	L-03A	L-02B					
	L-04A	L-03B					
	L-05A	L-04B					
	L-06A						

データ通信カード

L-02A
L-05A
L-02C
L-08C
L-03D